

HEAD OFFICE



1 Genting Link

#02-04, Perfect One

Singapore 349518



(+65) 6748 2277



(+65) 6744 0033



sales@hakko.com.sg



@hakkoproducts


How to use SMD Type: Shape Quad and examples

Supports rework environment with 3 types: quad, tunnel and spatula. This type is capable of heating plural pins or lead wires at once and is used for rework of SMDs.

** SMD TYPE Quad use it for removing QFPs.*

How to select the size

Select the head not by the number of pins but by the package size [length x width x height] including legs.




The tip before soldering



Apply solder to the tip end before operating.
** Applying sufficient solder makes removing easier*

Removing SOP



1. Apply the flux to the lead
2. Warm the IC
3. Removes it using tweezers, etc.